- (1) A circuit directory cardholder; and
 - (2) A circuit directory that has:
- (i) The circuit designation of each circuit;
- (ii) A description of the load of each circuit; and
- (iii) The rating or setting of the overcurrent protective device for each circuit.

§111.40-13 Rating.

Each panelboard must have a current rating not less than the feeder circuit capacity.

§111.40-15 Overcurrent device.

The total load on any overcurrent device located in a panelboard must not exceed 80 percent of its rating if, in normal operation, the load will continue for 3 hours or more; except if the assembly, including the overcurrent device, is rated for continuous duty at 100% of its rating.

Subpart 111.50—Overcurrent Protection

§111.50-1 Protection of equipment.

Overcurrent protection of electric equipment must meet the following listed subparts of this chapter:

- (a) Appliances, Subpart 111.77.
- (b) Generators, Subpart 111.12.
- (c) Motors, motor circuits, and controllers. Subpart 111.70.
 - (d) Transformers, Subpart 111.20.

§111.50-2 Systems integration.

The electrical characteristics of each overcurrent protective device must be compatible with other devices and its coordination must be considered in the design of the entire protective system.

Note to §111.50-2: The electrical characteristics of overcurrent protective devices may differ between standards. The interchangeability and compatibility of components complying with differing standards cannot be assumed.

[CGD 94–108, 61 FR 28279, June 4, 1996]

§111.50-3 Protection of conductors.

(a) *Purpose*. The purpose of overcurrent protection for conductors is to open the electric circuit if the current reaches a value that will cause an ex-

cessive or dangerous temperature in the conductor or conductor insulation. A grounded conductor is protected from overcurrent if a protective device of a suitable rating or setting is in each ungrounded conductor of the same circuit.

- (b) Overcurrent protection of conductors. Each conductor must be protected in accordance with its current carrying capacity, except a conductor for the following circuits which must meet the following listed subparts of this chapter:
- (1) Propulsion circuits, Subpart 111.35.
- (2) Steering circuits, subchapter F of this chapter.
 - (3) Motor circuits, Subpart 111.70.
- (4) Flexible cord and fixture wire for lighting circuits, Subpart 111.75.
- (5) Switchboard circuits, Subpart 111.30.
- (c) Fuses and circuitbreakers. If the allowable current-carrying capacity of the conductor does not correspond to a standard rating for fuses or circuitbreakers that meets Section 240.6 of NFPA NEC 2002 or IEC 92–202 (both incorporated by reference; see 46 CFR 110.10–1), then the next larger such rating is acceptable, except that:
- (1) This rating must not be larger than 150 percent of the current-carrying capacity of the conductor; and
- (2) The effect of temperature on the operation of fuses and thermally controlled circuitbreakers must be taken into consideration.
- (d) Parallel overcurrent protective devices. An overcurrent protective device must not be connected in parallel with another overcurrent protective device.
- (e) Thermal devices. No thermal cutout, thermal relay, or other device not designed to open a short circuit may be used for protection of a conductor against overcurrent due to a short circuit or ground, except in a motor circuit as described in Article 430 of NFPA NEC 2002 or in IEC 92–202.
- (f) Ungrounded conductors. A fuse or overcurrent trip unit of a circuit breaker must be in each ungrounded conductor. A branch switch or circuit breaker must open all conductors of the circuit, except grounded conductors.

§ 111.50-5

- (g) Grounded conductor. An overcurrent device must not be in a permanently grounded conductor, except:
- (1) An overcurrent device that simultaneously opens all conductors of the circuit, unless prohibited by §111.05–17 for the bus-tie feeder connecting the emergency and main switchboards; and
- (2) For motor-running protection described in Article 430 of NFPA NEC 2002 or in IEC 92-202.

[CGD 74–125A, 47 FR 15236, Apr. 8, 1982, as amended by CGD 94–108, 61 FR 28279, June 4, 1996; CGD 97–057, 62 FR 51047, Sept. 30, 1997; USCG–2003–16630, 73 FR 65197, Oct. 31, 2008]

§ 111.50-5 Location of overcurrent protective devices.

- (a) Location in circuit. Overcurrent devices must be at the point where the conductor to be protected receives its supply, except as follows:
- (1) The generator overcurrent protective device must be on the ship's service generator switchboard. (See §111.12–11(g) for additional requirements.)
- (2) The overcurrent protection for the shore connection conductors must meet §111.30–25.
- (3) If the overcurrent device that protects the larger conductors also protects the smaller conductors, an overcurrent device is not required at the supply to the smaller conductors.
- (4) If the overcurrent device protecting the primary side of a single phase transformer (two wire with single-voltage secondary) also protects the conductors connected to the secondary side, as determined by multiplying the current-carrying capacity of the secondary conductor by the secondary to primary transformer voltage ratio, and this protection meets \$111.20–15 of this chapter, an overcurrent device is not required at the supply to the secondary side conductors.
- (b) Location on vessel. Each overcurrent device:
 - (1) Must be:
 - (i) Readily accessible; and
- (ii) In a distribution panelboard, switchboard, motor controller, or similar enclosure; and
 - (2) Must not be:
- (i) Exposed to mechanical damage; and

(ii) Near an easily ignitable material or where explosive gas or vapor may accumulate.

§ 111.50-7 Enclosures.

- (a) Each enclosure of an overcurrent protective device must meet Sections 240–30 and 240–33 of NFPA NEC 2002 (incorporated by reference; see 46 CFR 110.10–1).
- (b) No enclosure may be exposed to the weather unless accepted by the Commandant.

[CGD 74–125A, 47 FR 15236, Apr. 8, 1982, as amended by USCG–2003–16630, 73 FR 65197, Oct. 31 2008]

§111.50-9 Disconnecting and guarding.

Disconnecting and guarding of overcurrent protective devices must meet Part IV of Article 240 of NFPA NEC 2002 (incorporated by reference; see 46 CFR 110.10-1).

[USCG-2003-16630, 73 FR 65197, Oct. 31, 2008]

Subpart 111.51—Coordination of Overcurrent Protective Devices

§111.51-1 Purpose.

The purpose of this subpart is to provide continuity of service for equipment vital to the propulsion, control or safety of the vessel under short-circuit conditions through coordination and selective operation of overcurrent protective devices.

§111.51-3 Protection of vital equipment.

- (a) The coordination of overcurrent protective devices must be demonstrated for all potential plant configurations.
- (b)Overcurrent protective devices must be installed so that:
- (1) A short-circuit on a circuit that is not vital to the propulsion, control, or safety of the vessel does not trip equipment that is vital: and
- (2) A short-circuit on a circuit that is vital to the propulsion, control, or safety of the vessel is cleared only by the protective device that is closest to the point of the short-circuit.

[CGD 74–125A, 47 FR 15236, Apr. 8, 1982, as amended by CGD 94–108, 62 FR 23908, May 1, 1997]